

Chinese Manufactured B-3

1	气筒后盖	Tube plug	21	保险板簧(2)	Safety spring
2	活塞簧托管销	Cocking block pin	22	扳机固定销	Trigger pin
3	托管	Cocking block	23	挡圈(2)	Ring
4	活塞簧	Piston spring	24	阻铁销	Sear pin
5	活塞结合	Piston	25	保险板螺钉	Safety screw
6	气碗	"U" type piston seal ring	26	簧座	Safety cocking block
7	活塞套筒结合	Air-room	27	保险板	Safety piece
8	扳机定位销(3)	Trigger pin	28	连杆结合	Lever
9	活塞套密封圈	Air-room ring	29	拉杆结合销	Lever pin
10	枪身	Body	30	拉杆结合	Operating arm
11	座块	Rear sight stand	31	螺钉(2)	Screw
12	高低调节螺钉	H-L screw	32	肩垫	Stock-end
13	沉头螺钉	Screw	33	装饰垫	Backing board
14	盘头螺钉	Screw	34	枪托	Stock
15	标尺板	Rear sight	35	枪托垫块	Plastic block
16	准星护罩	Front sight ring	36	枪托结合螺钉	Rear screw
17	准星	Front sight	37	螺钉	Front screw
18	扳机	Trigger	38	扳机护圈	Trigger circle
19	阻铁簧	Sear spring	39	垫圈(2)	Inside ring
20	阻铁	Sear	40	螺钉(2)	Side-screw

This schematic is provided as an informational guide. It is not instructional and we therefore assume no responsibility for those who use it without proper factory training.

